



Instruction Set H08B User's Manual

H08B Instruction Index

Instruction	Description	Cycles	Status Affected	Ref Page
BYTE-ORIENTED FILE REGISTER OPERATIONS				
ADDC	f,d,a Add W, F and C and place the result to W or F.	1	C,Z	5
ADDF	f,d,a Add W and F and place the result to W or F.	1	C,Z	6
ADDL	k Add constant k and W and place the result to W.	1	C,Z	7
ANDF	f,d,a AND operation W and F and place the result to W or F.	1	Z	8
ANDL	k AND operation K and W and place the result to W.	1	Z	9
CLRF	f,a Clear F	1	None	16
COMF	f,d,a Complement F and place the result to W or F.	1	Z	17
CPSE	f,a If F=W, skip the next instruction	1(2)(3)	None	18
CPSG	f,a If F>W, skip the next instruction.	1(2)(3)	None	19
CPSL	f,a If F<W, skip the next instruction.	1(2)(3)	None	20
DCF	f,d,a Subtract 1 of F value, place the result to W or F.	1	C,Z	22
DCSUZ	f,d,a Subtract 1 of F value, if the result ≠ 0, skip the next instruction and place it to W or F.	1(2)(3)	None	23
DCSZ	f,d,a Subtract 1 of F value, if the result = 0, skip the next instruction and place it to W or F.	1(2)(3)	None	24
INF	f,d,a Add 1 to F value and store the result to W or F.	1	C,Z	26
INSUZ	f,d,a Add 1 to F value, if the result ≠ 0, skip the next instruction and place it to W or F.	1(2)(3)	None	27
INSZ	f,d,a Add 1 to F value, if the result = 0, skip the next instruction and place it to W or F.	1(2)(3)	None	28
IORF	f,d,a Inclusive OR W and F, and place the result to W or F.	1	Z	29
IORL	k Inclusive OR constant k and W, and place the result to W.	1	Z	30
MVF	f,d,a Move W value to F (d=1) or move F value to W(d=0).	1	None	32
MVL	k Move constant k to W.	1	None	33
RETL	k Put the top stack value to PC and configure W value as k. The main program will execute from current PC value.	2	None	37
RLF	f,d,a Rotate left F and place the result to W or F.	1	Z	38
RLFC	f,d,a Rotate F value and C and place the result to W or F.	1	C,Z	39

Remark

f	Register	b	Register b bit
n	Memory address	k	8 bit constant
d	Data storage; d = 0 means the data is saved in accumulator W ; d = 1 means it is saved in register f.		
a	Memory address of data storage ,a=0 is saved in memory address (000H~0FFH)		

H08B Instruction Fast Index (continued)

Instruction	Description	Cycles	Status Affected	Ref Page
BYTE-ORIENTED FILE REGISTER OPERATIONS				
RRF	f,d,a Rotate right f and place the result to W or F.	1	Z	40
RRFC	f,d,a Rotate right f and C and place the result to W or F.	1	C,Z	41
SETF	f,a Configure F value as 0xFF.	1	None	42
SUBC	f,d,a Subtract w of F value and reverse C, then place the result to W or F.	1	C,Z	44
SUBF	f,d,a Subtract w of F value and place to result to W or F.	1	C,Z	45
SUBL	k Subtract constant k and W and place the result to W.	1	C,Z	46
SWPF	f,d,a Switch the high 4 bit and low 4 bit value and save the result to W or F.	1	None	47
TFSZ	f,a Test whether a specific bit value of F is 0. If so, skip the next instruction.	1(2)(3)	None	48
XORF	f,d,a Exclusive OR W and F and place the result to W or F.	1	Z	49
XORL	k XOR constant k and W, then places the result to W.	1	Z	50

Remark

f	Register	b	Register b bit
n	Memory address	k	8 bit constant
d	Data storage; d = 0 means the data is saved in accumulator W ; d = 1 means it is saved in register f.		
a	Memory address of data storage ,a=0 is saved in memory address (000H~0FFH)		

H08B Instruction Fast Index (continued)

Instruction		Description	Cycles	Status Affected	Ref Page
CONTROL OPERATIONS					
CALL	n,s	Save the PC value of next instruction to the uppermost stack layer and jump to address n.	2	None	15
CWDT		Clear watch dog timer to 0	1	TO	21
IDLE		Go to standby mode	1	IDLEB	25
JMP	n	Jump unconditionally to address n.	2	None	31
NOP		Blank instruction	1	None	34
RET	s	Return to main program from vice program and place the uppermost stack value into PC.	2	None	35
RETI	s	Return to main program from interrupt vice program and place the uppermost stack value placed into PC. Main program will be executed from current PC value.	2	GIE	36
SLP	f,a	Go to sleep mode		PD	43
BIT-ORIENTED FILE REGISTER OPERATIONS					
BCF	f,b,a	Configure a specific bit of F as 0.	1	None	10
BSF	f,b,a	Configure a specific bit of F as 1.	1	None	11
BTGF	f,b,a	NOT a specific bit of F.	1	None	12
BTSS	f,b,a	Test whether a specific bit value of F is 1. If so, skip the next instruction.	1(2)(3)	None	13
BTSZ	f,b,a	Test whether a specific bit value of F is 0. If so, skip the next instruction.	1(2)(3)	None	14

Remark

f	Register	b	Register b bit
n	Memory address	k	8 bit constant
d	Data storage; d = 0 means the data is saved in accumulator W ; d = 1 means it is saved in register f.		
a	Memory address of data storage ,a=0 saved in memory address (000H~0FFH)		

ADDC ADD w and Carry bit to f

Syntax: ADDC f, d, a
Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$
Operation: $(W) + (f) + (\text{Status}\langle C \rangle) \rightarrow \text{destination}$
Status Affected: C, Z

Description: Add accumulator W value, register f value and carry flag C together and place the result to d appointed register ;

If d = 0, the operation result will be placed into accumulator W ;

If d = 1, the operation result will be placed into register f ;

If a = 0, the operation result will be place into RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: ADDC REG, 0, 0

Before Instruction:

W=001H
REG(080H)=01FH
C=Z=0

After Instruction:

W=020H
REG(080H)=01FH
C=Z=0

Remark: d=0, the execution result will be placed into accumulator W.

Example 2: ADDC REG, 1, 0

Before Instruction:

W=001H
REG(070H)=00EH
C=1, Z=0

After Instruction:

W=001H
REG(070H)=010H
C=Z=0

Remark: d=1, the execution result will be placed into register f.

ADDF ADD w to F

Syntax: ADDF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(W) + (f) \rightarrow \text{destination}$

Status Affected: C, Z

Description: Add accumulator W value and register f value together, then place the result to d appointed register :

 If d = 0, the operation result will be placed into accumulator W ;

 If d = 1, the operation result will be placed into register f ;

 If a = 0, the operation result will be place into RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: ADDF REG, 0, 0

Before Instruction:

W=001H

REG(080H)=01FH

C=Z=0

After Instruction:

W=020H

REG(080H)=01FH

C=Z=0

Remark: d=0, the execution result will be placed into accumulator W..

Example 2: ADDF REG, 1

Before Instruction:

W=001H

REG(080H)=01FH

C=Z=0

After Instruction:

W=001H

REG(080H)=020H

C=Z=0

Remark: d=1, the execution result will be placed into register f. The default value is a=0, if program a=0, then this argument can not be added into this program.

ADDL ADD Literal to w

Syntax: ADDL k
Operands: $0 \leq k \leq 255$
Operation: $(W) + K \rightarrow W$
Status Affected: C, Z

Description: Add accumulator W value and k value, and place the result to accumulator W.

Words: 1

Cycles: 1

Example 1: ADDL 00FH

Before Instruction:

W=001H

C=Z=0

After Instruction:

W=010H

C=Z=0

Example 2: ADDL 00FH

Before Instruction:

W=071H

C=Z=0

After Instruction:

W=080H

C=Z=0

Example 3: ADDL 00FH

Before Instruction:

W=081H

C=Z=0

After Instruction:

W=090H

C=OV=Z=0

Example 4: ADDL 00FH

Before Instruction:

W=0F1H

C=Z=0

After Instruction:

W=000H

C=Z=1

Remark: The execution result > 0FFH, carry flag, C=1. If the result is 000H, the zero flag, Z=1.

ANDF AND w with F

Syntax: ANDF f, d, a
Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$
Operation: (W) AND (f) → destination
Status Affected: Z

Description: Logic AND accumulator W value and register f value, and place the result to d appointed register.

If d = 0, place the result to accumulator W ;

If d = 1, place the result to register f ;

IF a = 0, place the result to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: ANDF REG, 0

Before Instruction:

W=055H
REG(080H)=0AAH
C=Z=0

After Instruction:

W=000H
REG(080H)=0AAH
Z=1, C=0

Remark: If the result is 000H, the zero flag, Z=1. If the default value is a=0, when a=0, it is alright to not adding this argument into the program.

Example 2: ANDF REG, 1, 0

Before Instruction:

W=080H
REG(070H)=0FFH
C=Z=0

After Instruction:

W=080H
REG(070H)=080H
C=Z=0

ANDL AND Literal with w

Syntax: ANDL k

Operands: $0 \leq k \leq 255$

Operation: (W) AND k \rightarrow W

Status Affected: Z

Description: Logic AND accumulator W value and k value, and place the result to accumulator W.

Words: 1

Cycles: 1

Example 1: ANDL 0A0H

Before Instruction:

W=055H

C=Z=0

Remark: If the result is 000H, the zero flag bit Z=1.

After Instruction:

W=000H

Z=1, C=0

Example 2: ANDL 0FF0H

Before Instruction:

W=080H

C=Z=0

After Instruction:

W=080H

C=Z=0

BCF Bit Clear F

Syntax: BCF f, b, a
Operands: $0 \leq f \leq 255$; $0 \leq b \leq 7$; $a \in (0)$
Operation: $0 \rightarrow f < b >$
Status Affected: None
Description: Clear register f configuration as 0.
Words: 1
Cycles: 1
Example 1: BCF REG,2

Before Instruction:

REG(080H)=1111 1111B

After Instruction:

REG(080H)=1111 1011B

Remark: Clear BIT2of register REG as 0, other bits remain unchanged.

BSF Bit Set F

Syntax: BCF f, b, a

Operands: $0 \leq f \leq 255$; $0 \leq b \leq 7$; $a \in (0)$

Operation: $1 \rightarrow f < b >$

Status Affected: None

Description: Configure register f value as 1.

Words: 1

Cycles: 1

Example 1: BSF REG,2

Before Instruction:

REG(080H)=00000000B

After Instruction:

REG(080H)=00000100B

Remark: Configure BIT2 of REG as 1, other bits remain unchanged.

BTGF Bit ToGgle F

Syntax: BTGF f, b, a

Operands: $0 \leq f \leq 255$; $0 \leq b \leq 7$; $a \in (0)$

Operation: $\overline{(f < b >)} \rightarrow f < b >$

Status Affected: None

Description: Complement a specific bit of register.

Words: 1

Cycles: 1

Example 1: BTGF REG, 7, 0

Before Instruction:

REG(080H)=0111 1111B

Remark: Complement BIT7 of register, REG.

After Instruction:

REG(080H)=1111 1111B

BTSS Bit Test and Skip if Set

Syntax: BTSS f, b, a

Operands: $0 \leq f \leq 255$; $0 \leq b \leq 7$; $a \in (0)$

Operation: skip if $(f < b) = 1$

Status Affected: None

Description: Compare whether a specific bit of register is 1. Skip the next instruction if the bit is 1. If not, execute the next instruction.

Words: 1

Cycles: 1(2)(3)

Example 1:
BTSS REG, 7, 0
MVL 001H
NOP

Before Instruction:

WREG(02CH)=000H

REG(080H)=0FFH

After Instruction:

WREG(02CH)=000H

REG(080H)=0FFH

Remark: BIT7 of register, REG is 1, so skip the next instruction..

Example 2:
BTSS REG, 7, 0
MVL 001H
NOP

Before Instruction:

WREG(02CH)=000H

REG(080H)=07FH

After Instruction:

WREG(02CH)=001H

REG(080H)=07FH

Remark: BIT7 of register, REG is 0, so the program can execute the next instruction.

BTSZ Bit Test and Skip if Zero

Syntax: BTSZ f, b, a

Operands: $0 \leq f \leq 255$; $0 \leq b \leq 7$; $a \in (0)$

Operation: skip if $(f < b) = 0$

Status Affected: None

Description: Compare whether a specific bit of register is 0. Skip the next instruction if the bit is 0.
If not, execute the next instruction.

Words: 1

Cycles: 1(2)(3)

Example 1: BTSZ REG, 7, 0
 MVL 001H
 NOP

Before Instruction:

WREG(02CH)=000H
REG(080H)=0FFH

After Instruction:

WREG(02CH)=001H
REG(080H)=0FFH

Remark: BIT7 of register, REG is not 0, so the program can execute the next instruction.

Example 2: BTSZ REG, 7, 0
 MVL 001H
 NOP

Before Instruction:

WREG(02CH)=000H
REG(080H)=07FH

After Instruction:

WREG(02CH)=000H
REG(080H)=07FH

Remark: BIT7 of register, REG is 0, so skip the next instruction.

CLRF CLeaR F

Syntax: CLRF f, a

Operands: $0 \leq f \leq 255$; a \in (0)

Operation: 000H \rightarrow f

Status Affected: None

Description: Clear register f value.

Words: 1

Cycles: 1

Example 1: CLRF REG,0

Before Instruction:

REG(080H)=055H

Remark: Clear register, REG value as 0.

After Instruction:

REG(080H)=000H

COMF COMplement F

Syntax: COMF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $\overline{(f)}$ → destination

Status Affected: Z

Description: The value of register f is complemented and the result is stored in d appointed register.
If d = 0, the result is stored in accumulator W ;
If d = 1, the result is stored in register f ;
If a = 0, the result is stored in RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: COMF REG, 0, 0

Before Instruction:

WREG(02CH)=055H

REG(080H)=0FFH

Z=0

After Instruction:

WREG(02CH)=000H

REG(080H)=0FFH

Z=1

Example 2: COMF REG, 1, 0

Before Instruction:

WREG(02CH)=055H

REG(070H)=055H

Z=0

After Instruction:

WREG(02CH)=055H

REG(070H)=0AAH

Z=0

CPSE ComPare f with w, Skip if f Equal w

Syntax: CPSE f, a

Operands: $0 \leq f \leq 255$; $a \in (0)$

Operation: skip if (f) = (W)

Status Affected: None

Description: Compare register value and accumulator W value. If the value is equivalent, skip the next value. If the value is > or <, continue the next instruction.

Words: 1

Cycles: 1(2)

Example 1:
CPSE REG, 0
MVL 001H
NOP

Before Instruction:

WREG(02CH)=000H

REG(080H)=000H

After Instruction:

WREG(02CH)=000H

REG(080H)=000H

Remark: The value of register f and accumulator W is the same, skip the next instruction.

Example 2:
CPSE REG, 0
MVL 001H
NOP

Before Instruction:

WREG(02CH)=000H

REG(070H)=07FH

After Instruction:

WREG(02CH)=001H

REG(070H)=07FH

Remark: The value of register f and accumulator W is different, continue the next instruction.

CPSG ComPare f with w, Skip if f Greater than w

Syntax: CPSG f, a

Operands: $0 \leq f \leq 255$; $a \in (0)$

Operation: skip if $(f) > (W)$

Status Affected: None

Description: Compare the register value and accumulator W value.
If register value is greater than accumulator W value, skip the next instruction..
If register value is smaller than accumulator W value, continue the next instruction.

Words: 1

Cycles: 1(2)

Example 1:
CPSG REG, 0
MVL 00FH
NOP

Before Instruction:

WREG(02CH)=005H

REG(080H)=006H

After Instruction:

WREG(02CH)=005H

REG(080H)=006H

Remark: The value of register f is greater than accumulator W content, skip the next instruction.

Example 2:
CPSG REG, 0
MVL 00FH
NOP

Before Instruction:

WREG(02CH)=005H

REG(070H)=005H

After Instruction:

WREG(02CH)=00FH

REG(070H)=005H

Remark: The value of register f equals to accumulator W content, continue the next instruction.

CPSL ComPare f with w, Skip if f Less than w

Syntax: CPSL f, a

Operands: $0 \leq f \leq 255$; $a \in (0)$

Operation: skip if $(f) < (W)$

Status Affected: None

Description: Compare the register value and accumulator W value.
If register value is smaller than accumulator W value, skip the next instruction.
If register value is greater or equivalent to accumulator value, continue the next instruction.

Words: 1

Cycles: 1(2)

Example 1:
CPSL REG, 0
MVL 00FH
NOP

Before Instruction:

WREG(02CH)=005H

REG(080H)=004H

Remark: Register f value is smaller than accumulator W value, skip the next instruction.

After Instruction:

WREG(02CH)=005H

REG(080H)=004H

Example 2:
CPSL REG, 0
MVL 00FH
NOP

Before Instruction:

WREG(02CH)=005H

REG(070H)=005H

Remark: Register f value is equivalent to accumulator value, continue the next instruction.

After Instruction:

WREG(02CH)=00FH

REG(070H)=005H

CWDT Clear WatchDog Timer

Syntax: CWDT
Operands: None
Operation: 000H → Watch dog counter
Status Affected: Pstatus<TO>
Description: Clear CWDT value as 0
Words: 1
Cycles: 1
Example 1: CWDT

Before Instruction:

WDT counter = ???

After Instruction:

WDT counter = 000H
Pstatus<TO> = 0

DCF DeCrement F

Syntax: DCF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) - 1 \rightarrow \text{destination}$

Status Affected: C, Z

Description: Subtract 1 of register f value, and place back the result to d appointed register.
If d = 0, the result is placed to accumulator W ;
If d = 1, the result is placed to register f ;
If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: DCF REG, 0, 0

Before Instruction:

WREG(02CH)=055H
REG(080H)=0FFH
C=Z=0

Remark: If C has not been borrowed, C=1 ;

Example 2: DCF REG, 1, 0

Before Instruction:

WREG(02CH)=055H
REG(070H)=000H
C=Z=0

Remark: C has been borrowed, C=0 ;

Example 3: DCF REG, 1, 0

Before Instruction:

WREG(02CH)=055H
REG(080H)=080H
C=Z=0

Remark: C has not been borrowed, C=1

Example 4: DCF REG, 0, 0

Before Instruction:

WREG(02CH)=055H
REG(080H)=001H
C=Z=0

Remark: C has not been borrowed, C=1 ; the result after execution is 0, so Z=1.

After Instruction:

WREG(02CH)=0FEH
REG(080H)=0FFH
C=1, Z=0

After Instruction:

WREG(02CH)=055H
REG(070H)=0FFH
C=Z=0

After Instruction:

WREG(02CH)=055H
REG(080H)=07FH
C=1, Z=0

After Instruction:

WREG(02CH)=000H
REG(080H)=001H
C=Z=1

DCSUZ DeCrement f, Skip if Un-Zero

Syntax: DCSUZ f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) - 1 \rightarrow \text{destination}$, skip if destination $\neq 0$

Status Affected: None

Description: Compare the decremented register value with 0. If register value is not equal to 0, skip the next instruction. If the value is 0, continue the next instruction and place the result to d appointed register.

If d = 0, the result is placed in accumulator W ;

If d = 1, the result is placed in register f ;

If a = 0, the result is placed in RAM address (000H~0FFH).

Words: 1

Cycles: 1(2)(3)

Example 1: DCSUZ REG, 1, 0
 MVL 00AH
 NOP

Before Instruction:

WREG(02CH)=00FH

REG(080H)=001H

Remark: If the result is 0, continue to execute the next program, and the result will be placed in register REG.

Example 2: DCSUZ REG, 0, 0
 MVL 00AH
 NOP

Before Instruction:

WREG(02CH)=055H

REG(070H)=000H

Remark: If the result is not 0, skips the next instruction and places the result to accumulator W.

After Instruction:

WREG(02CH)=00AH

REG(080H)=000H

After Instruction:

WREG(02CH)=0FFH

REG(070H)=000H

DCSZ DeCrement f, Skip if Zero

Syntax: DCSZ f, d, a
Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$
Operation: $(f) - 1 \rightarrow \text{destination}$, skip if destination=0
Status Affected: None

Description: Compare the decremented register value with 0. If the register value equals to 0, skip the next instruction. If not, continue the next instruction and place the result back to d appointed register.
If d = 0, place the result to accumulator W ;
If d = 1, place the result to register f ;
If a = 0, place the result to RAM address (000H~0FFH).

Words: 1

Cycles: 1(2)(3)

Example 1:
DCSZ REG, 0, 0
MVL 00AH
NOP

Before Instruction:

WREG(02CH)=00FH
REG(080H)=001H

Remark: The result is 0, so skip the next instruction.

Example 2:
DCSZ REG, 1, 0
MVL 00AH
NOP

Before Instruction:

WREG(02CH)=055H
REG(070H)=000H

Remark: The result is not 0, so continue the next program and place the result to register REG.

After Instruction:

WREG(02CH)=000H
REG(080H)=001H

After Instruction:

WREG(02CH)=00AH
REG(070H)=0FFH

IDLE IDLE mode

Syntax: IDLE
Operands: None
Operation: CPU Halt

Status Affected: Pstatus<IDLEB>

Description: CPU accesses to idle mode, program blank instruction executes action.
It is recommended to add NOP instruction after IDLE instruction.

Words: 1

Cycles: 1

Example 1: IDLE
 NOP

Before Instruction:

Pstatus<IDLEB>=0

After Instruction:

Pstatus<IDLEB>=1

IDLE

NOP.....[program break here](#)

INF INcrement F

Syntax: INF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) + 1 \rightarrow \text{destination}$

Status Affected: C, Z

Description: Add 1 to the content of register f and place the result to d appointed register.
If d = 0, the result is placed to accumulator W ;
If d = 1, the result is placed to register f ;
If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: INF REG, 0, 0

Before Instruction:

WREG(02CH)=055H
REG(080H)=0FFH
C=Z=0

After Instruction:

WREG(02CH)=000H
REG(080H)=0FFH
C=Z=1

Remark: C is carried, so C=1. After execution, the result equals to 0, so Z=1.

Example 2: INF REG, 1, 0

Before Instruction:

WREG(02CH)=055H
REG(070H)=00FH
C=Z=0

After Instruction:

WREG(02CH)=055H
REG(070H)=010H
C=Z=0

Example 3: INF REG, 1, 0

Before Instruction:

WREG(02CH)=055H
REG(080H)=07FH
C=Z=0

After Instruction:

WREG(02CH)=055H
REG(080H)=080H
C=Z=0

INSUZ INcrement f, Skip if Un-Zero

Syntax: INSUZ f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) + 1 \rightarrow \text{destination}$, skip if destination $\neq 0$

Status Affected: None

Description: Compare the register incremented value with 0. If the register value is not 0, then skip the next instruction. If the value equals to 0, then continue executing next instruction and store the result to d appointed register.

If d = 0, the result is placed to accumulator W ;

If d = 1, the result is placed to register f ;

If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1(2)(3)

Example 1: INSUZ REG, 1, 0
 MVL 00AH
 NOP

Before Instruction:

WREG(02CH)=00FH

REG(080H)=0FFH

After Instruction:

WREG(02CH)=00AH

REG(080H)=000H

Remark: The result is 0, so continue the next program. The result will be placed back to register REG.

Example 2: INSUZ REG, 0, 0
 MVL 00AH
 NOP

Before Instruction:

WREG(02CH)=055H

REG(070H)=000H

After Instruction:

WREG(02CH)=001H

REG(070H)=000H

Remark: The result is not 0, so skip the next instruction. The result will be stored in accumulator W.

INSZ INcrement f, Skip if Zero

Syntax: INSZ f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) + 1 \rightarrow \text{destination}$, skip if destination=0

Status Affected: None

Description: Compare the incremented register value with 0. If the value is 0, skip the next instruction. If not equals to 0, continue the next instruction and store the result to d appointed register.
If d = 0, the result is placed to accumulator W ;
If d = 1, the result is placed to register f ;
If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1(2)(3)

Example 1:
INSZ REG, 0, 0
MVL 00AH
NOP

Before Instruction:

WREG(02CH)=00FH
REG(080H)=0FFH

Remark: The result is 0, skip the next instruction.

Example 2:
INSZ REG, 1, 0
MVL 00AH
NOP

Before Instruction:

WREG(02CH)=055H
REG(070H)=000H

Remark: The result is not 0, so continue the next instruction and place the result to register REG.

After Instruction:

WREG(02CH)=000H
REG(080H)=0FFH

After Instruction:

WREG(02CH)=00AH
REG(070H)=001H

IORF Inclusive OR w with F

Syntax: IORF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: (W) OR (f) \rightarrow destination

Status Affected: Z

Description: Inclusive OR accumulator W value and register f value and place the result to d appointed register.

If d = 0, the result is placed to accumulator W ;

If d = 1, the result is placed to register f ;

If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: IORF REG, 0, 0

Before Instruction:

WREG(02CH)=055H

REG(080H)=0AAH

Z=0

After Instruction:

WREG(02CH)=0FFH

REG(080H)=0AAH

Z=0

Example 2: IORF REG, 1, 0

Before Instruction:

WREG(02CH)=00FH

REG(070H)=0F0H

Z=0

After Instruction:

WREG(02CH)=00FH

REG(070H)=0FFH

Z=0

IORL Inclusive OR Literal with w

Syntax: IORL k

Operands: $0 \leq k \leq 255$

Operation: (W) OR k \rightarrow W

Status Affected: Z

Description: Inclusive OR accumulator W value and k and place the result back to accumulator W.

Words: 1

Cycles: 1

Example 1: IORL 055H

Before Instruction:

WREG(02CH)=0AAH

Z=0

After Instruction:

WREG(02CH)=0FFH

Z=0

Example 2: IORL 000H

Before Instruction:

WREG(02CH)=000H

Z=0

After Instruction:

WREG(02CH)=000H

Z=1

Remark: The result is 0, so Z=1.

JMP unconditional JuMP

Syntax: JMP n

Operands: $0 \leq n \leq 2047(07FFH)$

Operation: $n \rightarrow PC$

Status Affected: None

Description: Unconditionally jump to the appointed address n.

Words: 2

Cycles: 2

Example 1: LABEL: JMP NEXT

:

NEXT: NOP

Before Instruction:

PC = address (LABEL)

After Instruction:

PC= address (NEXT)

MVF MoVe F to w or MoVe w to F

Syntax: MVF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) \rightarrow W$, or $(W) \rightarrow f$

Status Affected: None

Description: Move register f value to accumulator W; or move accumulator W value to register f.
If $d = 0$, it means moving register f value to accumulator W ;
If $d = 1$, it means moving accumulator W value to register f ;
 $a = 0$ or $a = 1$ configuration must be determined by register f address of RAM :
If $a = 0$, it means register f existing in the appointed RAM address of 000H~0FFH.

Words: 1

Cycles: 1

Example 1: MVF REG, 0, 0

Before Instruction:

WREG(02CH)=055H
REG(080H)=0AAH
REG1(170H)=0FFH

After Instruction:

WREG(02CH)=0AAH
REG(080H)=0AAH
REG1(170H)=0FFH

Remark: $d=0$, it means moving register REG value to accumulator W.

Example 2: MVF REG1, 1, 0

Before Instruction:

WREG(02CH)=055H
REG1(170H)=0FFH
REG(080H)=0AAH

After Instruction:

WREG(02CH)=055H
REG1(170H)=055H
REG(080H)=0AAH

Remark: $d=1$, it means moving accumulator W value to register f.

MVL MoVe Literal to w

Syntax: MVL k

Operands: $0 \leq k \leq 255$

Operation: $k \rightarrow W$

Status Affected: None

Description: Move constant k to accumulator W.

Words: 1

Cycles: 1

Example 1: MVL 0FFH

Before Instruction:

WREG(02CH)=000H

After Instruction:

WREG(02CH)=0FFH

NOP No OPeration

Syntax: NOP

Operands: None

Operation: No operation

Status Affected: None

Description: No operation is executed, only delay for 1 instruction time.

Words: 1

Cycles: 1

Example 1: NOP

Remark: Blank instruction, only executing the delay time of 1 instruction cycle.

RET RETurn from subroutine

Syntax: RET

Operands: None

Operation: (TOS) → PC,

Status Affected: STKPTR<STKUN>, Pstatus<SKERR>

Description: Leave vice program and store stack pointer register value to PC.
When vice program is not called and STKPTR=000H, executes instruction RET may result to IC reset and STKUN flag may be configured as 1.
SKERR flag will be configured as 1.
TOS is not readable for users.

Words: 1

Cycles: 2

Example 1: RET

Before Instruction:

None

After Instruction:

PC=TOS

RETI RETurn from Interrupt

Syntax: RETI

Operands: None

Operation: (TOS) → PC, 1 → GIE

Status Affected: GIE, STKPTR<STKUN>, Pstatus<SKERR>

Description: Return form interrupt and store the stack pointer register value to PC. Interrupt enable pin is configured again as 1.

When vice program is not called and STKPTR=000H, execute RETI instruction will lead to IC reset. STKUN flag will be configured as 1 so as SKERR flag.

TOS is not readable for users.

Words: 1

Cycles: 2

Example 1: RETI 1

Before Instruction:

None

RETL RETurn Literal to w

Syntax: RETL k

Operands: $0 \leq k \leq 255$

Operation: $k \rightarrow W, (TOS) \rightarrow PC$

Status Affected: STKPTR<STKUN>, Pstatus<SKERR>

Description: Return from vice program to main program. While returning the instruction, constant k value will be loaded to accumulator W.

This instruction is often implemented in look-up-table function.

When vice program is not called and STKPTR=000H, executing RETL instruction may reset the IC. STKUN flag will be configured as 1, so as SKERR flag.

Words: 1

Cycles: 2

Example 1:

```
LABEL:  MVL      001H
         CALL    TABLE
         .
         .
         .
TABLE:  ADDF     PCLATL, 1, 0
         RETL    055H
         RETL    0AAH
```

Before Instruction:

WREG(02CH)=001H

After Instruction:

WREG(02CH)=0AAH


Remark: While returning to main program, constant k will be loaded to accumulator W.
This example presents how to write Offset value of PCLATL to determine the value of TABLE.

RLF Rotate Left F (no carry)

Syntax: RLF f, d, a
Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$
Operation: (f<n>) → destination <n+1 > ,
 (f<7>) → destination < 0 >

Status Affected: Z

Description: Rotate left f value.
 If d = 0, the result is placed to accumulator W ;
 If d = 1, the result is placed to register f ;
 If a = 0, the result is placed to RAM address (000H~0FFH).



Words: 1
Cycles: 1
Example 1: RLF REG, 1, 0

Before Instruction:

WREG(02CH)=00FH
 REG(080H)=0AAH
 Z=0

After Instruction:

WREG(02CH)=00FH
 REG(080H)=055H
 Z=0

Example 2: RLF REG, 0, 0

Before Instruction:

WREG(02CH)=00FH
 REG(07FH)=000H
 Z=0

After Instruction:

WREG(02CH)=000H
 REG(07FH)=000H
 Z=1

Example 3: RLF REG, 0, 0

Before Instruction:

WREG(02CH)=00FH
 REG(080H)=055H
 Z=0

After Instruction:


WREG(02CH)=0AAH
 REG(080H)=055H
 Z=0

RLFC Rotate Left F through Carry

Syntax: RLFC f, d, a
Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$
Operation: (f<n>) → destination <n+1 >,
 (f<7>) → Status< C >,
 Status< C > → destination < 0 >

Status Affected: C, Z

Description: Rotate left register f value and carry flag C.
 If d = 0, the result is placed to accumulator W ;
 If d = 1, the result is placed to register f ;
 If a = 0, the result is placed to RAM address (000H~0FFH).



Words: 1
Cycles: 1
Example 1: RLFC REG, 1, 0

Before Instruction:

WREG(02CH)=00FH
 REG(080H)=0AAH
 C=Z=0

After Instruction:

WREG(02CH)=00FH
 REG(080H)=054H
 C=1, Z=0

Example 2: RLFC REG, 0, 0

Before Instruction:

WREG(02CH)=0FH
 REG(070H)=0EAH
 C=Z=0

After Instruction:

WREG(02CH)=0D4H
 REG(070H)=0EAH
 C=1, Z=0

Example 3: RLFC REG, 1, 0

Before Instruction:

WREG(02CH)=00FH
 REG(070H)=080H
 C=Z=0

After Instruction:


WREG(02CH)=00FH
 REG(070H)=000H
 C=Z=1

RRF Rotate Right F (no carry)

Syntax: RRF f, d, a
Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$
Operation: (f<n>) → destination <n - 1 > ,
 (f<0>) → destination < 7 >

Status Affected: Z

Description: Rotate right the register f value.
 If d = 0, the result is placed to accumulator W ;
 If d = 1, the result is placed to register f ;
 If a = 0, the result is placed to RAM address (000H~0FFH).



Words: 1
Cycles: 1
Example 1: RRF REG, 1, 0

Before Instruction:

WREG(02CH)=00FH
 REG(080H)=0AAH
 Z=0

After Instruction:

WREG(02CH)=00FH
 REG(080H)=055H
 Z=0

Example 2: RRF REG, 0, 0

Before Instruction:

WREG(02CH)=00FH
 REG(07FH)=000H
 Z=0

After Instruction:

WREG(02CH)=000H
 REG(07FH)=000H
 Z=1

Example 3: RRF REG, 0, 0

Before Instruction:

WREG(02CH)=00FH
 REG(080H)=055H
 Z=0

After Instruction:


WREG(02CH)=0AAH
 REG(080H)=055H
 Z=0

RRFC Rotate Right F through Carry

Syntax: RRFC f, d, a
Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$
Operation: (f<n>) → destination <n-1 >,
 (f<0>) → Status< C >,
 Status< C > → destination < 7 >

Status Affected: C, Z

Description: Rotate right the register f value and carry flag C.
 If d = 0, the result is placed to accumulator W ;
 If d = 1, the result is placed to register f ;
 If a = 0, the result is placed to RAM address (000H~0FFH).



Words: 1
Cycles: 1
Example 1: RRFC REG, 1, 0

Before Instruction:

WREG(02CH)=00FH
 REG(080H)=0AAH
 C=Z=0

After Instruction:

WREG(02CH)=00FH
 REG(080H)=055H
 C=Z=0

Example 2: RRFC REG, 0, 0

Before Instruction:

WREG(02CH)=00FH
 REG(07FH)=055H
 C=1, Z=0

After Instruction:

WREG(02CH)=0AAH
 REG(07FH)=055H
 C=1, Z=0

Example 3: RRFC REG, 1, 0

Before Instruction:

WREG(02CH)=00FH
 REG(07FH)=001H
 C=Z=0

After Instruction:

WREG(02CH)=00FH
 REG(07FH)=000H
 C=Z=1

SETF SET F

Syntax: SETF f, a

Operands: $0 \leq f \leq 255$; $a \in (0)$

Operation: $0FFH \rightarrow f$

Status Affected: None

Description: Configure all the contents of register f to 1.
a = 0 or a = 1 is determined by RAM address of register f :
If a = 0, it means that register f exists in the appointed RAM address of 000H to 0FFH

Words: 1

Cycles: 1

Example 1: SETF REG, 0

Before Instruction:

WREG(02CH)=00FH

REG(080H)=0AAH

After Instruction:

WREG(02CH)=00FH

REG(080H)=0FFH

SLP enter SLeeP mode

Syntax: SLP

Operands: None

Operation: 1 → PD

Status Affected: Pstatus<PD>

Description: CPU accesses into sleep mode, oscillator stop operating.

Words: 1

Cycles: 1

Example 1: SLP
 NOP

Before Instruction:

PD=0

After Instruction:

PD=1

SUBC SUBtract w from f with Carry

Syntax: SUBC f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) - (W) - \overline{(C)} \rightarrow \text{destination}$

Status Affected: C, Z

Description: Subtract accumulator W, carry flag C's reversed value of register f and place the result to d.
If d = 0, the result is placed to accumulator W ;
If d = 1, the result is placed to register f ;
If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: SUBC REG, 0, 0

Before Instruction:

WREG=001H
REG(080H)=001H
C=1, Z=0

After Instruction:

WREG=000H
REG(080H)=001H
C=Z=1

Remark: C has not been borrowed, so C=1. The result is 0, so Z=1.

Example 2: SUBF REG, 1, 0

Before Instruction:

WREG=000H
REG(07FH)=080H
C=Z=0

After Instruction:

WREG=000H
REG(07FH)=07FH
C=1, Z=0

Remark: C has not been borrowed, so C=1.

SUBF SUBtract w from F

Syntax: SUBF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: $(f) - (W) \rightarrow \text{destination}$

Status Affected: C, Z

Description: Subtract accumulator W value of register f and place the result to d.
If d = 0, the result is placed to accumulator W ;
If d = 1, the result is placed to register f ;
If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: SUBF REG, 0, 0

Before Instruction:

WREG=001H
REG(080H)=001H
C=Z=0

After Instruction:

WREG=000H
REG(080H)=001H
C=Z=1

Remark: C has not been borrowed, so C=1. The result is 0, so Z=1.

Example 2: SUBF REG, 1, 0

Before Instruction:

WREG=001H
REG(07FH)=080H
C=Z=0

After Instruction:

WREG=001H
REG(07FH)=07FH
C=1, Z=0

Remark: C has not been borrowed, so C=1 ; .

SUBL SUBtract w from Literal

Syntax: SUBL k

Operands: $0 \leq k \leq 255$

Operation: $K - (W) \rightarrow W$

Status Affected: C, Z

Description: Subtract constant k and accumulator W value and place the result back to accumulator W.

Words: 1

Cycles: 1

Example 1: SUBL 001H

Before Instruction:

WREG=001H

C=Z=0

Remark: C has not been borrowed, so C=1. The result is 0, so Z=1.

Example 2: SUBL 080H

Before Instruction:

WREG=001H

C=Z=0

Remark: C has not been borrowed, so C=1.

Example 3: SUBL 07FH

Before Instruction:

WREG=0FFH

C=Z=0

Remark: C has been borrowed, so C=0.

Example 4: SUBL 000H

Before Instruction:

WREG=001H

C=Z=0

Remark: C has been borrowed, so C=0

After Instruction:

WREG=000H

C=Z=1

After Instruction:

WREG=07FH

C=1, Z=0

After Instruction:

WREG=080H

C= Z=0

After Instruction:

WREG=0FFH

C=Z=0

SWPF SWaP F

Syntax: SWPF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: (f<3:0>) → destination<7:4>
 (f<7:4>) → destination<3:0>

Status Affected: None

Description: Switch high and low 4 bit value of register f.
 If d = 0, the result is placed to accumulator W ;
 If d = 1, the result is placed to register f ;
 If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: SWPF REG, 1, 0

Before Instruction:

WREG=001H
REG(080H)=05AH

After Instruction:

WREG=001H
REG(080H)=0A5H

TFSZ Test F, Skip if Zero

Syntax: TFSZ f, a

Operands: $0 \leq f \leq 255$; a \in (0)

Operation: skip if f = 0

Status Affected: None

Description: If register f value is 0, skip the next instruction. If the value is unequal to 0, the next instruction is executed.

a = 0 or a = 1 is determined by RAM address of register f :

If a = 0, it means that register f exists in appointed RAM address of 000H to 0FFH.

Words: 1

Cycles: 1(2)(3)

Example 1: TFSZ REG, 0
 MVL 00FH
 NOP

Before Instruction:

WREG(02CH)=005H

REG(080H)=000H

Remark: Register f value is 0, skip the next instruction.

After Instruction:

WREG(02CH)=005H

REG(080H)=000

Example 2: TFSZ REG, 0
 MVL 00FH
 NOP

Before Instruction:

WREG(02CH)=005H

REG(070H)=001H

Remark: Register f value is not 0, continue the next instruction.

After Instruction:

WREG(02CH)=00FH

REG(070H)=001H

XORF eXclusive OR w with F

Syntax: XORF f, d, a

Operands: $0 \leq f \leq 255$; $d \in (0, 1)$; $a \in (0)$

Operation: (W) XOR (f) \rightarrow destination

Status Affected: Z

Description: Exclusive OR the constant k and accumulator w and place the result back to d.
If d = 0, the result is placed to accumulator w ;
If d = 1, the result is placed to register f ;
If a = 0, the result is placed to RAM address (000H~0FFH).

Words: 1

Cycles: 1

Example 1: XORF REG, 0, 0

Before Instruction:

WREG(02CH)=0AAH
REG(080H)=055H
Z=0

After Instruction:

WREG(02CH)=0FFH
REG(080H)=055H
Z=0

Remark: XOR: if both values equal, the result is 0 ; if both values are unequal, the result is 1.

Example 2: XORF REG, 1, 0

Before Instruction:

WREG(02CH)=0FFH
REG(070H)=0FFH
Z=0

After Instruction:

WREG(02CH)=0FFH
REG(070H)=000H
Z=1

Remark: The result is 0, so Z=1.

XOR: if both values equal, the result is 0 ; if both values are unequal, the result is 1.

Example 3: XORF REG, 0, 0

Before Instruction:

WREG(02CH)=000H
REG(080H)=000H
Z=0

After Instruction:

WREG(02CH)=000H
REG(080H)=000H
Z=1

Remark: The result is 0, so Z=1.

XOR: if both values equal, the result is 0 ; if both values are unequal, the result is 1.

XORL eXclusive OR Literal with w

Syntax: XORL k

Operands: $0 \leq f \leq 255$

Operation: (W) XOR k \rightarrow W

Status Affected: Z

Description: Exclusive OR the constant k and accumulator w and place the result back to accumulator W.

Words: 1

Cycles: 1

Example 1: XORL 055H

Before Instruction:

WREG(02CH)=0AAH

Z=0

After Instruction:

WREG(02CH)=0FFH

Z=0

Remark: XOR: if both values equal, the result is 0 ; if both values are unequal, the result is 1.

Example 2: XORL 0FFH

Before Instruction:

WREG(02CH)=0FFH

Z=0

After Instruction:

WREG(02CH)=000H

N=0

Remark: The result is 0, so Z=1.

XOR: if both values equal, the result is 0 ; if both values are unequal, the result is 1.

Example 3: XORL 000H

Before Instruction:

WREG(02CH)=000H

Z=0

After Instruction:

WREG(02CH)=000H

Z=1

Remark: The result is 0, so Z=1.

XOR: if both values equal, the result is 0 ; if both values are unequal, the result is 1.

REVISION HISTORY

以下描述本文件差異較大的地方，而標點符號與字形的改變不在此描述範圍。

Version	Page	Summary
V01	ALL	First Version
V02	ALL	Layout revision Add in Page 21 Pstatus<TO> and Example description. Add in Page 44 Pstatus<PD>.